



638 RT 10 WEST CLINTON, IL 61727 217-935-2384

AFM Switch Panel

for 87-93 Mustang
INSTRUCTION

Thank you for purchasing an ***AFM*** product. If you have any question's please call 217-935-2384

To install your ***AFM*** switch panel.

1. Remove the factory ash tray.
2. Slide the hold down bracket (this is the flat piece that the screw goes through) into where the ash tray was, set it flat facing side to side and pull it up and it will click into place against the tabs that held the ash tray in place.
3. Run your wires to the switch panel opening. You can slide the wires up the bottom sides of the console, so you don't have to take it up. If you do need power you can splice into the power wire for the cigarette lighter.
4. Plug in all your wires to the switch panel and put it down into place and secure with screw.
5. Test and make sure you have the wire placement correct.